



Overview

Infi-tex recommends you to evaluate the Sampler mat with either a Windows or Linux OS. The software can work on a Mac but in our experience driver installation is more tricky.

Web Browser

The sampler mat has been designed for use with the Google Chrome web browser. Whilst it may be possible to evaluate our software with another browser, unpredictable behaviour may occur.

Driver Installation

On Windows or Mac you must first install an FTDI Virtual COM port (VCP) driver. This can be downloaded from here:

<https://ftdichip.com/drivers/vcp-drivers/>

On Linux, the driver is likely already included.

Demo Software

The infi-tex demonstration software can be downloaded from here:

<https://github.com/jacobjelen/InfiSample/archive/refs/heads/browser-production.zip>

Complete the following steps to run the demo:

- Extract the compressed archive containing the Infi-tex GUI software
- Connect the sampler to a PC using the supplied USB lead
- Open the directory containing the Infi-tex files
- Double click the "Infitex_Sampler" file to run the software
- Click the red link on the left hand side to enable "Experimental Web Platform features"
- In the top left hand corner, click the "Connect" button
- Select the "Infi-tex Sample Sheet" from the list
- Press the blue "Connect" button to activate the mat

Note - If you disconnect and reconnect the device you MUST refresh the web page and reconnect the Infi-Tex GUI software.